



## RECTANGULAR POCKET–LARGE P/N 1047-3

## INSTALLATION INSTRUCTIONS

For additional assistance call 888-514-0083 between 8AM-5PM EST or email: [info@pactoolmounts.com](mailto:info@pactoolmounts.com)

### CAUTION

To avoid the risk of personal injury, property damage or product damage, please use the included fasteners for mounting.

- \* The bracket must be securely mounted to a stable surface and material.
- \* When mounting bracket to PAC TRAC aluminum products **P/N 7000**, **P/N 7020**, **P/N 7040**, **P/N 7050** with the included Trac Lok inserts **P/N 7016**, torque the screws to a maximum 15 in-lbs.
- \* PAC recommends regular and frequent inspections to be certain of proper operation and installation.



**FIGURE 1**

(Thru Mounting Method)

| MTG. HARDWARE                                                                       |            |                                     | QTY |
|-------------------------------------------------------------------------------------|------------|-------------------------------------|-----|
|    | P/N 2049   | #10-24 x 3/4 S.S.<br>Pan Head Screw | 4   |
|    | P/N 7016   | Trac Lok Insert                     | 4   |
|  | P/N 3017   | 1/4-20 x 1 S.S.<br>Pan Head Screw   | 4   |
|  | P/N 2069LN | 1/4-20 Nylon Locking Nut            | 4   |

**FIGURE 2**

(PAC TRAC Mounting)

