

Safety Message to Installers of Warning Light Equipment

⚠ WARNING

People's lives depend on your proper installation and servicing of Federal Signal products. It is important to read and follow all instructions shipped with this product and the original product. In addition, listed below are some other important safety instructions and precautions you should follow:

- To properly install the lighting system, you must have a good understanding of automotive systems, along with proficiency in the installation and use of safety warning equipment.
- Do not install equipment or route wiring in the deployment path of an airbag.
- If a vehicle seat is temporarily removed, verify with the vehicle manufacturer if the seat needs to be recalibrated for proper airbag deployment.
- You should frequently inspect the light system to ensure that it is operating properly and that it is securely attached to the vehicle.
- When drilling into a vehicle structure, be sure that both sides of the surface are clear of anything that could be damaged.
- Refer to the instructions packed with related products for additional precautions and information.
- File these instructions in a safe place and refer to them when maintaining and/or reinstalling the product.
- Do not stare directly into the lights at a close range or permanent damage to your eyesight may occur.

Failure to follow all safety precautions and instructions may result in property damage, serious injury, or death.

Product Overview

This publication has instructions for permanently mounting the Split Vision SLR to a vehicle. One kit is supplied with VSLR3 and two kits with VSLR6 and VSLR8 models. For electrical installation instructions, refer to the installation and maintenance instructions packed with the lightbar.

Unpacking the Kit

After unpacking the kit, inspect it for damage that may have occurred in transit. If it has been damaged, do not attempt to install or operate it. File a claim immediately with the carrier, stating the extent of damage. Carefully check all envelopes, shipping labels, and tags before removing or destroying them. Ensure that the parts in the Kit Contents List are included in the package. If you are missing any parts, contact Customer Support at 1-800-264-3578, 7 a.m. to 5 p.m., Monday through Friday (CT).


Mounting the Split Vision SLR on a Vehicle

Table 1 Mounting kit contents

One kit is supplied with VSLR3 and two kits with VSLR6 and VSLR8 models.

Qty.	Description	Part Number
4	Screw, 1/4" x 3/4", Type AB, HWH, SS BLK OX	7011183-12
8	Pad, Mounting, Rubber	8422A033
4	Nut, Hex, 3/8"-16, HCR	7059124
4	Washer, 3/8", S.S.	7072A035
4	Lockwasher, Split, 3/8", S.S.	7074A046
1	Bracket, Mounting, LH	8652206-L
1	Bracket, Mounting, RH	8652206-R
Optional Brackets		
Qty.	Description	Part Number
1	Bracket, Short, Mounting, LH	865200957-L
1	Bracket, Short, Mounting, RH	865200957-R

Figure 1 RH bracket attached to passenger side of lightba



Installing the Mounting Brackets on the Lightbar

To install the mounting brackets on the lightbar:

1. Carefully turn the light assembly upside down and place it on a surface that will not scratch the domes.

2. Assemble one LH and RH mounting bracket on the factory installed carriage bolts using 3/8"-16 hex nuts, 3/8" flat washers, and 3/8" split lockwashers as shown in Figures 1 and 2. Secure the brackets in position; torque the nuts to 20 ft-lb.
3. For the Model VSLR6 and VSLR8, repeat steps 1 and 2 on the other half of the lightbar.

Installing the Lightbar on the Vehicle

To install the lightbar on the vehicle.

⚠ WARNING


ROOF SUPPORT STRUCTURE: *There is a roof support member that spans the distance between the driver and passenger side. DO NOT DRILL THROUGH THIS MEMBER! Adjust any hole locations until the holes can be drilled without going through this member.*

⚠ WARNING

HEAVY OBJECT: *Use lifting aids and proper lifting techniques when removing or replacing the lightbar. Failure to follow this warning may cause personal injury.*

1. See Figure 2. Position the lightbar on the vehicle roof at the desired location. The lightbar should be positioned with the pods aligned facing forward. In addition, ensure that the lightbar does not interfere with the operation of other apparatus.

Figure 2 Lightbar with brackets installed



NOTICE

DRILLING PRECAUTIONS: *When drilling holes, check the area into which you are drilling to be sure you do not damage vehicle components while drilling. All drilled holes should be de-burred and all sharp edges should be smoothed. All wire routings going through drilled holes should be protected by a grommet or convolute/split loom tubing.*


2. Using the mounting brackets as templates, scribe four drill-position marks on the mounting surface.
3. For VSLR6 and VSLR8 models, repeat steps 1 and 2 on the other half of the lightbar.

Mounting the Split Vision SLR on a Vehicle

4. Before drilling, move the lightbar(s) out of the way. Drill 0.199" (#8 drill) diameter holes at the scribed drill-position marks.
5. Place the lightbar in position on the roof. For proper drainage, tilt the nose of the lightbar downward, using three mounting pads in back and one mounting pad in front on each bracket.
6. See Figure 3. Secure the lightbar to the roof using the 1/4" x 3/4" black stainless steel thread-forming screws and tighten them securely. The Split Vision SLR should now be solidly anchored to the roof.
7. Ensure that all fasteners are properly tightened.

IMPORTANT: Frequently inspect the lightbar to ensure that all fasteners and brackets are tight.

Figure 3 Bracket secured to vehicle roof



Getting Technical Support and Service

For technical support and service, please contact:

Service Department

Federal Signal Corporation

Phone: 1-800-433-9132

Fax: 1-800-343-9706

Email: empserviceinfo@fedsig.com



FEDERAL SIGNAL
Safety and Security Systems

2645 Federal Signal Drive
University Park, Illinois 60484-3167

www.fedsig.com

Customer Support

Police/Fire-EMS: 800-264-3578 • +1 708 534-3400

Work Truck: 800-824-0254 • +1 708 534-3400

Technical Support: 800-433-9132 • +1 708 534-3400

© Copyright 2019 Federal Signal Corporation