



PERFORMANCE ADVANTAGE COMPANY
www.pactoolmounts.com

1-2018 A
INS-K5050,K5060

SUPER ADJUSTAMOUNT KIT P/N K5050 ☐
EXT. SUPER ADJUSTAMOUNT KIT P/N K5060 ☐

INSTALLATION INSTRUCTIONS

For additional assistance call 888-514-0083 between 8AM-5PM EST or email: info@pactoolmounts.com

CAUTION

To avoid the risk of personal injury, property damage or product damage, please use the included fasteners for mounting.

- * The bracket must be securely mounted to a stable surface and material.
- * When mounting bracket to PAC TRAC aluminum products **P/N 7000, P/N 7020, P/N 7040, P/N 7050** with the included Trac Lok inserts **P/N 7016**, torque the screws to a maximum 15 in-lbs.
- * If using optional Channel Nuts **P/N 3023 or P/N 3024**, torque the screws to a maximum 25 in-lbs.
- * PAC recommends regular and frequent inspections to be certain of proper operation and installation.



MTG. HARDWARE for PAC TRAC PAC Fastener Packet P/N 7029	QTY
 P/N 2049 #10-24 x 3/4 S.S. S.S. Pan Head Screw	2
 P/N 7016 Trac Lok Insert	2

STANDARD MTG. HARDWARE	QTY
 P/N 3017 1/4-20 x 1 S.S. S.S. Pan Head Screw	2
 P/N 2069LN 1/4-20 Nylon Locking Nut	2




Bracket Mounting


(PAC TRAC Mounting)



(Thru Mounting Method)






❖ Additional holes may be required to suit application and avoid interference with channel nuts.




Bracket Adjustment

To adjust the module position, remove and reposition the channel nuts as shown.




**Push and Rotate nut
in strut channel.**

To set strap length, loosen clamp screws and adjust to suit application.



**Excess strap length may be cut after
final adjustments have been
performed.**

To insert channel cushion, center over strut and press in. Lubricate with a soap & water solution underside of channel cushion to assist in assembly.



**APPLY SOAP AND WATER SOLUTION TO THESE AREAS TO
FACILITATE INSTALLATION!**